

Brookstone®

WEATHERCAST™

Wireless 5-Day Forecaster Alarm Clock

ACCUWEATHER.COM® FORECASTS—
BEAMED TO YOU FREE



TABLE OF CONTENTS

Warnings and Cautions	2-4
Location of Controls.....	5
Location of Controls and Icons	6
Weather Icons.....	7
Installing the Batteries.....	8
Operation.....	9-10
Clock and Alarm Operation.....	11-13
Care and Maintenance.....	13
Troubleshooting	14-16
Warranty.....	17-18

WARNING

1. Use indoors only.
2. Close attention is necessary when this unit is operated near children.
Do not allow children to play with this unit. It is not a toy.
3. Do not allow children to play with any plastic bags that accompany this unit.
Plastic bags may present a hazard to young children.
4. Never operate this unit if it is not working properly, if it has been dropped, damaged or dropped into water.
5. The unit should be situated away from heat sources such as direct sunlight, radiators, heat registers, stoves or other heat-producing appliances.
6. Never drop or insert objects into any openings.
7. Do not perform any servicing on the unit.
8. Do not try to disassemble unit.

FCC COMPLIANCE INFORMATION

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protections against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with these instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

Note: If harmful interference to radio or television reception should occur, determined by turning the product off and on, the user is encouraged to correct interference by trying one or more of the following measures:


- Relocate the receiving antenna.
- Increase the separation between equipment and receiver.
- Connect product to an outlet on a circuit different from receiver.
- Consult an experienced radio/TV technician for help.

BATTERY PRECAUTIONS

- Dispose of the old batteries properly. Do not dispose of the old batteries in a fire.
- Do not leave the batteries where a child or pet could play with or swallow them. If the batteries are swallowed, contact a physician immediately.
- The batteries may explode if mistreated. Do not attempt to recharge or disassemble the batteries.
- Use only fresh batteries of the required size and type. Do not mix old and new batteries, different types of batteries, or rechargeable batteries of different capacities.


LOCATION OF CONTROLS

1. Time Zone
2. Battery Compartment
3. Fahrenheit/Celsius
4. Alarm 1 On/Off Button
5. Alarm Set Button
6. Favorites Button
7. Alarm 2 On/Off Button
8. Left Button
9. Snooze Bar
10. Right Button



LOCATION OF CONTROLS AND ICONS

1. Alarm 1 On/Off Button
2. Current Temperature
3. Hi/Lo Current Temps
4. Current Weather Icon
5. Current Time
6. Alarm 2 On/Off Button
7. Signal Strength
8. "Feels Like" Temperature
9. Alarm 1 & 2 Times
10. 4 Day Outlook
11. Selected City



WEATHER ICONS

Sun



Partly Cloudy



Cloudy



Blustery



Wind and Rain



Snow



Drizzle



Wintry Mix



Cloudy and Breezy



Thunderstorms




Haze



Flurries



INSTALLING THE BATTERIES

When the 4 AA batteries are running low, the low battery icon  will display, indicating that the batteries should be replaced.

1. Remove the door of the BATTERY COMPARTMENT.
2. Place 4 new AA batteries into the BATTERY COMPARTMENT according to the polarity indicators.

Note: Make sure the ribbon tab inside the battery compartment is under the first two batteries to ensure easy battery removal.

3. Replace the BATTERY COMPARTMENT door securely.

Note: The unit automatically receives a weather forecast from one to four hours after installing the batteries and updates continuously as the forecast changes.

WEATHERCAST OPERATION

SELECTING LOCATIONS



The unit provides the forecast for 152 locations in the United States.

Press the RIGHT or LEFT arrow button on the top of the unit repeatedly until your desired location appears on the display. The locations are organized alphabetically by state, then by city.

Note: Press and hold the RIGHT or LEFT arrow buttons to scroll through the list faster.

“FAVORITES” PRESET BUTTON

You can store up to five locations from the list of 152 cities as favorites.

1. To save a favorite, simply press and hold the FAVORITES button when the desired location appears on the screen. The  icon will illuminate for 3 seconds.
2. To remove a favorite, press and hold the FAVORITES button while on the selection you wish to remove, and the  icon will flash once.
3. One press of the FAVORITES button will allow you to scroll through favorite locations.

Note: If you try to add a favorite when you have already assigned five favorites, you will see the message “FAVORIT FULL” flash on the screen.

You will need to delete an existing favorite before you can add another.

Favorites settings will be preserved when batteries are removed.

VIEWING TEMPERATURE IN CELSIUS/FAHRENHEIT

The unit automatically displays the temperature in Fahrenheit.

To view the temperature in Celsius, use a small pointed object to press the F/C button located inside the battery compartment. Screen will show CELSIUS for 5 seconds to confirm choice.


Repeat this process to change back to Fahrenheit and the screen will show FAHRHT for 5 seconds to confirm choice.

“FEELS LIKE” TEMPERATURE

Your WeatherCast Alarm Clock shows the current “feels-like” temperature. This is a combination of wind-chill in the winter and heat-index in the summer.

Note: When you first power-up your device, the “feels-like” temperature may not appear at the same time as the current temperature.

“NO COVERAGE” MESSAGE

 will appear when your device has been unable to receive a signal for an extended period. Check our map at <http://map.myambient.com> to ensure that your location receives coverage from our network.

BATTERY LOW INDICATOR

 will appear when the device's batteries are low and need to be replaced.

CLOCK AND ALARM OPERATION

The time sets and updates automatically via satellite feed when you insert the batteries.

TIME ZONE

There are eight time zones programmed into your clock.

1. To change the default time zone display, open the BATTERY COMPARTMENT COVER on the bottom of the clock.
2. Press the TIME ZONE button to select your time zone.

The available time zones are:

ATLANTC TZ.	Atlantic Standard Time
EASTERN TZ.	Eastern Standard Time
CENTRAL TZ.	Central Standard Time
MTN TZ.	Mountain Standard Time
ARIZONA TZ.	Mountain Standard Time
PACIFIC TZ.	Pacific Standard Time
ALASKA TZ.	Alaska Standard Time
HAWAII TZ.	Hawaii Standard Time

3. Close the CONTROL COMPARTMENT COVER.

BACKLIGHT

Press the SNOOZE button and the backlight will illuminate for 5 seconds.

SETTING AND ACTIVATING THE ALARM

1. Press and hold the ALARM SET button for 2 seconds. The clock will go into Alarm Set mode. Alarm 1 time will flash.
2. Press the FORWARD/BACK buttons to scroll to the desired alarm time—hold down the FORWARD/BACK buttons to accelerate scrolling.
3. Press the ALARM SET button to save Alarm 1 time. Alarm 2 time will flash.
4. Press the FORWARD/BACK buttons to scroll to the desired alarm time—hold down the FORWARD/BACK buttons to accelerate scrolling.
5. Press ALARM SET to save Alarm 2 time. If ALARM SET is not pressed after setting either alarm, the alarm time will be saved and the clock will display after a few seconds.
6. Activate the alarms by pressing the ALARM 1 or ALARM 2 buttons on the top of the unit. When the button is in the “up” position the alarm is activated and the alarm time will appear on the display.
7. When the alarm sounds, the backlight will illuminate for 5 seconds.

Note: The buzzer incrementally increases in volume, reaching its loudest setting in 30 seconds.

DEACTIVATING THE ALARM

1. The ALARM 1 and/or ALARM 2 button must be in the “up” position to activate the alarm.
2. When the alarm sounds, press the ALARM 1 or ALARM 2 button into its “down” position to shut off the alarm.
3. The buzzer will sound for 15 minutes if the alarm is not turned off or the SNOOZE button isn't pressed. The alarm will then automatically reset for the following day.

USING SNOOZE

1. When the alarm is sounding, press the SNOOZE button to activate Snooze.
2. The alarm will sound again in 10 minutes. You may repeat this action 6 times. After the 6th time, the alarm buzzer will continue to sound for 15 minutes if the alarm is not manually turned off. The alarm will then automatically reset for the following day.
3. While Snooze is activated, the alarm time will flash.

CARE AND MAINTENANCE

- Wipe the unit with a soft, dry, clean cloth.

TROUBLESHOOTING

ISSUE

RESOLUTION

Display shows no information.

Ensure batteries are fresh and installed correctly.

No network signal.

Go to <http://map.myambient.com> and enter your zip code. If you are in an area without a lot of coverage, move the device to another location in your home or office for better reception.

Time is not correct.

Press the TIME ZONES button until the correct area is displayed.

Ensure batteries are fresh and installed correctly.

Only part of the screen is showing any data.

We send data to your WeatherCast Alarm Clock in discrete parts, so if your unit is only showing data on one part of the screen, or only some of the 152 cities, it's likely that the next update your unit receives will remedy this situation. If you've waited four hours or more without seeing the rest of the screen display data, there may be a problem with your device.

TROUBLESHOOTING (CONT.)

ISSUE

RESOLUTION

I don't see any bars next to the signal strength indicator.

This means that you're in an area that has poor reception. Try moving the unit closer to a window or upstairs. If you've moved it all over and still don't get any bars of signal, go to <http://map.myambient.com> to check your area for signal coverage.

My clock's time is correct, but it still shows an incorrect or outdated forecast.

This is almost always the result of "lagging," a condition that occurs when your device is not receiving a consistently strong signal. Try changing the location where you keep the WeatherCast Alarm Clock. We recommend that you keep it somewhere where it shows at least two bars of signal strength.

TROUBLESHOOTING (CONT.)

ISSUE

RESOLUTION

The temperature outside is different from what the device is saying.

The temperature readings and forecasts on your WeatherCast Alarm Clock aren't received from a local sensor—the information comes from wireless updates from Accuweather.com®. Also, the current outside temperature may vary from the meteorological information we receive for your location.

Will this device work outside of the United States?

Sorry, at present we only send data to Ambient Devices within the United States.

What can I do to improve battery life?

Your WeatherCast Alarm Clock is designed to use very little battery power when it receives a strong signal. If it's in an area with inconsistent or weak signal, it will work harder to make sure it updates properly. The best thing you can do is ensure it's in an area where it receives three bars of signal strength.

I have a question that's not answered here.

Please visit our support site: www.myambient.com/support
Call: 1-866-311-1999; 9AM to 5PM, EST
Or contact us anytime: support@ambientdevices.com

ONE (1) YEAR LIMITED WARRANTY

Brookstone® warrants this product against defects in materials and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option, Brookstone will either 1) repair the defect at no charge, using new or refurbished replacement parts, or 2) replace the product with a new product that is at least functionally equivalent to the original product, or 3) provide a store credit in the amount of the purchase price of the original product. A replacement product or part, including a user-installable part installed in accordance with instructions provided by Brookstone, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Brookstone's property. When a store credit is given, the original product must be returned to Brookstone and becomes Brookstone's property.

Obtaining Service: To obtain warranty service, call Brookstone Limited Warranty Service at 1-800-292-9819. Please be prepared to describe the product that needs service and the nature of the problem. A purchase receipt is required. All repairs and replacements must be authorized in advance. Service options, parts availability and response times will vary. You are responsible for delivery and the cost of delivery of the product or any parts to the authorized service center for replacement, per our instructions.

Limits and Exclusions: Coverage under this Limited Warranty is limited to the United States of America, including the District of Columbia and the U.S. Territories of Guam, Puerto Rico, and the U.S. Virgin Islands. This Limited Warranty applies only to products manufactured for Brookstone that can be identified by the "Brookstone" trademark, trade name, or logo affixed to them or their packaging. The Limited Warranty does not apply to any non-Brookstone products. Manufacturers or suppliers other than Brookstone may provide their own warranties to the purchaser,

but Brookstone, in so far as permitted by law, provides these products "as is." This warranty does not apply to: a) damage caused by failure to follow instructions relating to product's use or the installation of components; b) damage caused by accident, abuse, misuse, fire, floods, earthquake or other external causes; c) damage caused by service performed by anyone who is not a representative of Brookstone; d) accessories used in conjunction with a covered product; e) a product or part that has been modified to alter functionality or capability; f) items intended to be periodically replaced by the purchaser during the normal life of the product including, without limitation, batteries or light bulbs; g) any product sold "as is" including, without limitation, floor demonstration models and refurbished items; or h) a product that is used commercially or for a commercial purpose.

BROOKSTONE SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, BROOKSTONE DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF BROOKSTONE CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY.

Some states disallow the exclusion or limitation of incidental or consequential damages or how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Brookstone®

A WORLD OF INNOVATION

Since 1965, people have come to Brookstone to see what's new, discover smart solutions to everyday problems—and have some fun. At Brookstone, we believe there's always a better way to do things. And we created a world of innovation to prove it.

Merrimack, New Hampshire USA 03054 • 800-846-3000 • www.Brookstone.com

627919